



You have just been connected to your new water main. To flush your water line, locate the closest available tap to where the water comes into the home, like an outside hose faucet, laundry sink or bathtub. Fully open the cold water tap, and let the water run for at least 5 minutes. Then move to the next highest floor and repeat flushing for at least 5 minutes. Sediment and metals can collect in the aerator screen located at the tip of your faucets. The aerator should be removed prior to flushing.

Flushing will help maintain optimum water quality by removing sediment, rust, metals, or any particulates that may have come loose from your property's water service line.

If you have any questions or concerns about your water quality, please call us at 312-744-8190.

